


Checking binding



To display the Host/CableCARD Binding screen: From TiVo Central select Messages & Settings> Account & System Information > CableCARD Decoders > Configure CableCARD 1 (or 2) > CableCARD menu > **Host/CableCARD Binding**.

The Host/CableCARD Binding screen displays **has been validated** when the CableCARD is bound (paired) with the slot in which it is installed.

When the CableCARD is not bound, this screen will pop up when you tune to a copy-protected channel, and the text will prompt you to report the Host ID and CableCARD to your cable provider.

Note: A CableCARD that is not bound can still display encrypted channels – just not copy protected channels.