

QUICK TOUR - QUICKMODE™

It's not fast-forward, it's QuickMode! QuickMode lets you play a show 30% faster, while also letting you hear what everyone is saying.

QuickMode is available while you're watching a recorded show, or if you're "behind" live TV (for instance, if you have rewound a show that's airing live). Here's how to use it:

- 1.** While playing a recorded show, press PLAY - at the top of the circle around the PAUSE button in the center of your remote - to bring up the status bar.
- 2.** Press SELECT- the round button at the center of the arrows circle - to start Quick Mode.
- 3.** When you're finished watching in QuickMode, press SELECT again to resume watching at normal speed.

With QuickMode, you get the speed of fast-forward, without missing any of the details.