

THE INFO BANNER

The info banner allows you to access the Audio Description track, and it displays the show's title, description, ratings, and other information. It appears whenever you change the channel. To view the info banner while watching a show, press INFO - the second button down on the right of the TiVo button. Icons in the info banner are shortcuts to corresponding features. Use the UP and DOWN arrows - the top and bottom of the arrows circle just below the TiVo button on your remote - to move to an icon, then press SELECT.



Record: The show is currently recording. Select this icon to stop the recording.



Tuner Swap: (Not available on TiVo Mini.) Select this icon for information about what's playing on the other tuners. When no recordings are in progress, the icon will be all gray.



Audio: Select this icon for alternate audio tracks, if available.



Audio Description: Select this icon for audio description track, if available.



Dolby® Audio: When a Dolby Audio track is available, this icon will be visible.



Closed Caption: Turn closed captioning on or off.