

CONNECTING TO A HOST DVR (TIVO MINI ONLY)

HOW DO I CONNECT TO A HOST TIVO DVR?

- You chose a host DVR when your TiVo Mini went through Guided Setup. If you want to change your host DVR, select 'Settings & Messages,' then 'Settings,' then 'Remote & Devices.' Choose 'Connected TiVo DVR' to select a new host.

MY TIVO MINI CAN'T FIND A HOST TIVO DVR.

- Make sure that the TiVo Mini and the host TiVo DVR are on the same TiVo account, that both boxes are on the same network, that the host TiVo DVR is turned on, and that both the TiVo Mini and the host TiVo DVR have network connections. To test your the network connection, go to the TiVo Central screen and select 'Settings & Messages,' then 'Settings,' then 'Network,' then 'Connect to the TiVo service now.'

I HAVE MORE THAN ONE TIVO DVR IN MY HOME NETWORK; HOW CAN I CHANGE THE DEFAULT HOST?

- The TiVo DVR you selected during Guided Setup becomes the default host DVR, but you can change the host at any time. From the TiVo Central screen, select 'Settings & Messages,' then 'Settings,' then 'Remote & Devices.' Choose 'Connected TiVo DVR' to select a new host.