

BACK PANEL - TIVO MINI

When facing the back of the TiVo Mini, the following connectors are arranged left to right.

1. **MoCA®**. If using a MoCA home network, connects the TiVo Mini to your home network. Connect the Coaxial RF cable coming from the wall.
2. **Component Video Output**. Connects to a TV or A/V system to provide video only. Component video provides a high-definition picture using a Component video cable (available at tivo.com/store). Connect a separate cable (like the Composite (A/V) cable below) for audio.
3. **Composite Audio/Video Output (A/V)**. Connects to a TV or A/V system to provide audio and video. Composite video provides very good standard definition picture quality using a Composite video cable (available at tivo.com/store). It does not provide high-definition video.
4. **HDMI®**. Connects to a TV, A/V receiver, or home theater system. The HDMI port provides a pure digital connection for high-definition video and digital audio all in one cable.
5. **Ethernet**. Use this jack to connect the TiVo Mini to your home network using an Ethernet cable.
6. **USB**. Reserved for future use.
7. **Power**. Connects to A/C power. CAUTION: TO PREVENT ELECTRICAL SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, AND FULLY INSERT.