

CONNECTING YOUR TIVO BOX

I DON'T SEE THE WELCOME SCREEN WHEN I PLUG IN MY TIVO BOX FOR THE FIRST TIME.

- Make sure cables are connected from the OUT jack of one device to the IN jack of the next. Never connect OUT to OUT or IN to IN.
- Make sure your TV is displaying the appropriate video source. Use the Input, Source, or TV/Video button on your TV's remote to change video sources. If you are having trouble changing the video source, refer to your TV owner's manual.
- If your TiVo box is connected to an A/V receiver, and you are having trouble finding the correct input, try connecting the TiVo box directly to the TV instead.
- The cables you are using to connect your TiVo box to your TV or other equipment may be damaged or defective. Try using cables that you know are working properly.