



Start Here

Follow these easy steps to connect your TiVo Roamio DVR

Welcome! Start Here ▶▶

Setting up your TiVo® Roamio DVR is easy.

Activate the TiVo® service (if you haven't already).

The TiVo service is what makes your TiVo Roamio smart. It includes everything from your program listings to OnePasses and WishList® searches—all the cool features you've heard about.

Some TiVo DVRs are sold with a TiVo service plan. If yours was not, activate the TiVo service at www.tivo.com/activate or call TiVo Customer Support at 1-877-367-8486. You'll need your 15-digit TiVo Service Number (TSN), found on the label on the back of the Roamio.

Write it here for reference _____.

About TV programming sources

You can receive TV on your TiVo Roamio from a cable provider or from an HDTV antenna.

For cable programming, the TiVo Roamio needs **one Multi-Stream CableCARD™ decoder (M-CARD)**, available from your cable company.

You don't need to wait for your CableCARD decoder. Start connecting your TiVo Roamio now. You can install the CableCARD decoder later. For instructions, see the "Installing a CableCARD" insert that came with your TiVo Roamio.

Visit tivo.com/cablecardhelp for more information and step-by-step instructions.

To get started connecting your TiVo Roamio, go to **step 1**.

Set up your TiVo Roamio™ in 7 easy steps.

▶▶ **1**

Order a CableCARD decoder from your cable company

(Skip this step if you use an HDTV antenna to receive TV.)

If you receive cable TV from a cable provider, you'll need a multi-stream CableCARD decoder to receive HD and digital cable channels.


Order **one Multi-Stream CableCARD (M-CARD)** from your cable company and **disconnect your digital cable box** (if you have one). The M-CARD will replace your digital cable box. For CableCARD installation instructions, see the "Installing a CableCARD" insert that came with your TiVo Roamio.

Once you install your CableCARD, simply follow the on-screen instructions to set it up. During setup, you will need to call your cable company to activate (or "pair") your card with your TiVo Roamio. For CableCARD activation "hotline" numbers for many cable companies, and for more information and help, visit tivo.com/cablecardhelp.


You don't have to wait for your CableCARD to set up your TiVo Roamio. Continue to step 2.

2


Get to know your cables




HDMI® cable for high definition video and digital audio — **recommended for HD setup.**



Ethernet cable for connecting to the Internet through a wired network if not using MoCA.



Coaxial RF cable for receiving a cable signal and/or for connecting to the Internet through a MoCA network.



Power adapter (included).

7

Complete Guided Setup


Turn on your TV. After the TiVo Roamio starts up, you'll see a Welcome screen.

When you see the Welcome screen, you're ready to begin **Guided Setup**. Just follow the on-screen instructions.

You should complete Guided Setup even if you don't yet have a CableCARD decoder.

Note: If you don't see the Welcome screen, use the Input, Source, or TV/Video button on your TV remote or TV to select the correct video input source.

Once you've completed Guided Setup, turn this poster over to learn more about using your TiVo Roamio!



6

Plug in the power adapter

The TiVo Roamio's front panel displays a green light at startup.

5

Connect to your TV

Connect an HDMI cable from the HDMI port of the TiVo box to the HDMI IN port on the back of your TV.

If your TV does not have an HDMI port, see tivo.com/support for additional installation instructions.

4


Connect to the Internet

The TiVo Roamio needs a high-speed network connection to receive program listings, TiVo service updates, and on-demand content. The wired and wireless connection methods listed below are all sufficient for these purposes. **However, if you plan to have multiple TiVo boxes in your home and would like to stream shows between them, or if you want to stream shows to your iPad® or iPhone® using the TiVo Stream (sold separately), you must use a wired connection (Ethernet or MoCA®).**

Choose one of the connection types below. (Don't worry, you can always change this later.)



Wireless – Use your DVR's built-in wireless connection. You don't need to connect any additional cables or adapters.



Ethernet (wired) – Connect an Ethernet cable from the TiVo DVR's ETHERNET port to an open port on your router or to an Ethernet jack in your wall.




MoCA (wired) – MoCA (Multimedia over Coax Alliance) gives you the same high-speed connection you get through a wired Ethernet cable, but it delivers it through your existing coax cable—the same cable you use to get cable TV. If you already have a MoCA network in your home, connect your TiVo Roamio to your MoCA network using a MoCA network adapter (available at tivo.com/store). If you don't have a MoCA network yet, visit tivo.com/moca to learn how easy it is to get started.

(To MoCA network adapter)

Need some help?

For more info on setting up or using your TiVo Roamio, see the **Viewer's Guide** available online.

tivo.com/howto




Get to know TiVo Roamio™.

TiVo Central

When you finish Guided Setup, you'll see the **TiVo Central**® screen. This is the starting point for everything you do with your TiVo Roamio.

You can always reach the **TiVo Central** screen by pressing the TiVo button on your remote control.



My Shows

All of your recordings, streaming videos, and downloaded or transferred shows appear in the **My Shows** list. The left column contains categories that help you quickly locate shows in the list.

Highlight any title in **My Shows** (even a show that's still recording) and press **PLAY** to watch the show.



The TiVo Roamio Remote

Press the **TiVo button** at any time to go to the TiVo Central screen. Press it twice to get to your My Shows list from any other screen.

Program the **Volume**, **Mute**, and **TV Power** buttons to control your TV. Go to **Settings > Remote, CableCARD, and Devices**.

Control playback of live TV and recorded shows: fast-forward, rewind, pause, or play in slow-motion.

Replay repeats the last 8 seconds of the show. Press and hold to jump to the beginning.

In the TiVo menus or program guide, use the remote control's arrow buttons to move to the option you want, then press **SELECT**.

Use **THUMBS UP** or **THUMBS DOWN** to rate shows, collections, or video providers for TiVo Suggestions.


Advance moves forward in 30-second increments; press and hold to jump to the end.

The **A B C D** buttons sort and filter views. Look for the on-screen tips.



Video On Demand

What you want to watch, when you want to watch it. Just select **Find TV, Movies, & Videos** for available on-demand options.




Want to learn more?

See the online Viewer's Guide to find out about all the other cool things you can do with your TiVo Roamio.

tivo.com/howto

OnePass


OnePass gathers every episode of a series available from any of your video providers and adds them right to your My Shows list. If it's not available on TV or on demand, OnePass fills in the gaps with episodes from other streaming video providers like Netflix, Amazon Prime, and more.



Music & Photos

TiVo Roamio is really an entire digital home entertainment center, with access to your photos, music, and more!

From the **TiVo Central** screen, select **Music & Photos**.



Legal Notices

This product contains software copyright © 2015 TiVo Inc. All rights reserved.

Your use of this product is subject to TiVo's User Agreement and Privacy Policy, visit www.tivo.com/legal for the latest versions.

TiVo, TiVo Central, TiVo Roamio, the TiVo logos, the Thumbs Up and Thumbs Down logos, the Instant Replay logo, the Jump logo, and the WishList are trademarks or registered trademarks of TiVo Inc. or its subsidiaries worldwide.

Patented. U.S. patent numbers at www.tivo.com/patents.

Amazon, Amazon.com, and the Amazon.com logo are registered trademarks of Amazon.com, Inc. or its affiliates.

AOL is a registered trademark of AOL Inc.

CableCARD is a trademark of Cable Television Laboratories, Inc.

Manufactured under license from Dolby Laboratories.

Dolby and the double-D symbol are trademarks of Dolby Laboratories.

HDMI, the HDMI logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

Hulu and Hulu Plus are trademarks of Hulu, LLC.

iPad and iPhone are registered trademarks of Apple Inc.

MoCA is a registered trademark of Multimedia over Coax Alliance in the U.S. and other countries.

Netflix is a registered trademark of Netflix, Inc.

YouTube is a trademark of Google Inc.

All other trademarks are the properties of their respective owners.

This product contains open source software. Notices and licenses are provided in a system information screen and at tivo.com/linux, and are incorporated herein by reference. For open source software included in this product in executable form, if required by the applicable open source license, you may obtain a copy of the corresponding source code at any time during the period required by sending a money order or check for US\$10 to: TiVo Inc., 2160 Gold Street, San Jose, CA 95002, attn: Legal Department. TiVo also makes source code available at tivo.com/linux.

SDCC-00146-001 A6

FCC statement to the user

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. To maintain compliance with FCC RF exposure compliance requirements, please follow operation instructions as documented in this manual.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.


The availability of some specific channels and/or operational frequency bands are country dependent and are firmware programmed at the factory to match the intended destination. The firmware setting is not accessible by the end user.

Compliance Information

Model numbers: TCD846500 (Roamio), TCD846000 (Roamio Plus); TCD840300 (Roamio Pro); RC30A00, RC30B00 (Remote)
FCC IDs: TGN-TCDB465 (Roamio), TGN-TCDB460 (Roamio Plus/Pro), TGN-RC30 (Remote)

Askey International Corporation
800 Corporate Way, Suite B
Fremont, CA 94538

Model numbers: WLU5054 (Roamio), WLU5200 (Roamio Plus/Pro)
FCC IDs: H8N-WLU5054 (Roamio), H8N-WLU5200 (Roamio Plus/Pro)



TiVo DVR Limited Warranty

90 Days Free Labor | One Year Parts Exchange

WHO IS COVERED?

You must have proof of purchase to receive warranty service. A sales receipt or other document showing that you purchased the product is considered proof of purchase.

WHAT IS COVERED?

Each TiVo DVR is manufactured from parts and components that are new or equivalent to new in accordance with industry-standard practices. TiVo warrants that the DVR will be free from defects in materials and workmanship during the limited warranty period described herein. The limited warranty coverage begins the day you purchase the product as further described in the following text. For 90 days from the purchase date, the DVR will be replaced with a repaired, renewed or comparable product (whichever is deemed necessary by TiVo) if it becomes defective or inoperative. This exchange is done without charge to you for parts and labor (except applicable taxes, if any). You will be responsible for the cost of shipping. From 90 days to 1 year from the date of purchase, your DVR will be replaced with a repaired, renewed, or comparable product (whichever is deemed necessary by TiVo) if it becomes defective or inoperative. You will be responsible for all labor and shipping costs. Contact Customer Support at tivo.com/support or 877-367-8486 to obtain your cost (labor costs) for exchange.

All products, including replacement products, are covered only for the original warranty period. When the warranty on the original product expires, the warranty on the replacement product also expires. After one year from the date of purchase, you pay for the replacement of all parts, and for all labor and shipping charges.

WHAT IS EXCLUDED?

Your warranty does not cover:

- Labor charges for installation or setup of the product.
- Any taxes imposed on TiVo for units replaced or repaired under this warranty.
- Installation, performance of, or repair of: audio/video cabling, telephone line, or accessory attachments used with the product.
- Product replacement because of damage due to misuse, accident, lightning damage, unauthorized repair, or other cause not within the control of TiVo Inc. Please note that removing the cover of the DVR for any reason voids the warranty.
- Reception transmission problems caused by signal conditions, telephone line, or cable or antenna systems outside the unit.
- Damages to, or viruses that may infect your DVR or other devices arising from the use of unauthorized third party devices in connection with your DVR.
- Incidental or consequential damages resulting from the product. (Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you.)
- A product that has been modified or adapted to enable it to operate in any country other than the country for which it was designed, damaged by these modifications.
- A product used for commercial or institutional purposes.
- Access connections (telephone or broadband), including charges from your communications provider.

MAKE SURE YOU KEEP:

Please keep your sales receipt or other document showing proof of purchase. Attach it to this guide and keep both nearby. Also keep the original box and packing material in case you need to return your product.

BEFORE YOU REQUEST WARRANTY SERVICE

Please check the troubleshooting advice found at tivo.com/support before calling Customer Support. Following the troubleshooting tips contained therein may save you a call to Customer Support.

TO GET WARRANTY SERVICE...

If you believe you need service for your DVR, contact Customer Support at tivo.com/support or 877-367-8486. A representative will go through a diagnostic checklist with you. If it is determined that the product needs to be exchanged, you will receive a return authorization number. The representative will give you complete shipping details.

TO GET OUT-OF-WARRANTY SERVICE...

Out-of-warranty service can be obtained at a nominal cost for replacement and handling. To obtain out-of-warranty service contact Customer Support at tivo.com/support or 877-367-8486 to obtain the cost of out-of-warranty exchange for your product.

REMEMBER...

Record the model and service numbers found on the product below:

MODEL # _____

SERVICE # _____

All implied warranties, including implied warranties of merchantability and fitness for a particular purpose, are limited in duration to the duration of this express warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. This warranty gives you specific legal rights. You may have other rights which vary from state to state (or jurisdiction to jurisdiction). TIVO'S RESPONSIBILITY FOR MALFUNCTIONS AND DEFECTS IN DVRS IS LIMITED TO REPAIR AND REPLACEMENT AS SET FORTH IN THIS LIMITED WARRANTY. ALL EXPRESS AND IMPLIED WARRANTIES FOR THE DVR, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTIES OF AND ALL CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED IN DURATION TO THE LIMITED WARRANTY PERIOD SET FORTH ABOVE AND NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, WILL APPLY AFTER SUCH PERIOD. Some states (or jurisdictions) do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. TIVO DOES NOT ACCEPT LIABILITY BEYOND THE REMEDIES SET FORTH IN THIS LIMITED WARRANTY OR LIABILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION ANY LIABILITY FOR PRODUCTS NOT BEING AVAILABLE FOR USE OR FOR LOST DATA. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Safety Instructions

Save These Safety Instructions.

Before you begin

Make sure all your equipment is turned off and the TiVo DVR is unplugged.

Your TiVo DVR is only capable of supporting the weight of one or two common A/V components such as VCRs, DVD players, or A/V receivers (provided they have four good, broad, padded feet that distribute the weight near the corners of the TiVo DVR).

Also, avoid stacking your TiVo DVR on top of other electronic components — such as DVD players, A/V receivers — or the vents of your TV.

This product is for use only with listed ITE (Information Technology Equipment).

Safety Information

This product was designed and manufactured to meet strict quality and safety standards. There are, however, some installation and operation precautions of which you should be particularly aware. Please read these instructions before operating the equipment and save them for future reference.

1. Read Instructions — All the safety and operating instructions should be read and understood before the appliance is operated.
2. Retain Instructions — The safety and operating instructions should be retained for future reference.
3. Heed Warnings — All warnings on the appliance and in the operating instructions should be followed.
4. Follow Instructions — All operating and use instructions should be followed.
5. Water and Moisture — The appliance should not be used near water - for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, near a swimming pool, etc.
6. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.
7. Tilt/Stability — All televisions must comply with recommended international global safety standards for tilt and stability properties of their cabinet design. Do not compromise these design standards by applying excessive pull force to the front, or top, of the cabinet, which could ultimately overturn the product. Also, do not endanger yourself, or children, by placing electronic equipment/toys on top of the cabinet. Such items could unexpectedly fall from the top of the set and cause product damage and/or personal injury.
8. Ventilation — The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or placed in a built-in installation, such as a bookcase or cabinet that